

75mm*75mm
128g

MINI THUNDER



POWER BANK

USER MANUAL


Please refer to this manual before using the product

INTRODUCTION

Thank you for choosing "The MINI THUNDER" portable power bank. This product is a rechargeable battery (power bank) that can be used to power mobile devices.

The stored energy after a full charge is about 10000mAh which will provide an Output of 22.5W from the USB, 20W from USB-Type-C and 10W & 22.5W from the Attach wire output. For the best use of the power bank and for your safety, please Read these instructions carefully.

Digital Display Indicator.



PACKAGE CONTAINS
1X POWERBANK.
1X TYPE-C DATA CABLE.

TO CHARGE POWER BANK

To charge the power bank, use the included USB-A to USB-C cable and connect it to The input port on the power bank alternatively you can also use PD input cable as Well.

***MAKE SURE TO USE THE ORIGINAL MINIMUM 18W SUPER FAST CHARGING ADAPTER**

While charging the power bank, digital display which shows the battery percentage Of power bank will flash to indicate charging status. If you are using a fast-charging Adapter it will show the fast-charging icon on the display.

Fast charging icon



When charging is completed the percentage shows 100% on the display.

TO CHARGE PHONE OR DEVICE

Use your phone or other devices charging cable to connect the USB-A connector to Output port on the power bank. Connect the other end of the cable to your device Charging should commence automatically.

You can also use the attached cable to charge your devices.

If your phone or device cable uses a USB-C port(PD cable), then you can also plug it Into the USB-C port on the power bank.

If charging doesn't start, press the On/Off button to start charging.

TO CHECK REMAINING CAPACITY

Press the On/Off button and the digital display will show the percentage of Remaining capacity.

The digital display will turn off automatically after about 30 seconds.

SPECIFICATIONS

Model Name: MINI THUNDER

Battery type: Lithium-Polymer

Battery capacity: 10000mAh.

Input Power: 5V/3A, 9V/2A,

Output Power:

Attach Type-c: 5V/3A, 9V/2.22A, 12V/1.67A, 10V/2.25A

Attach Lighting: 5V/2A

USB-C: 5V/3A, 9V/2.22A, 12V/1.67A

USB-A:5V/3A, 9V/2A, 10V/2.25A, 12V/1.5A

SAFETY

Use only original adapter for charging, otherwise you may cause damage to the Device. The product is not suitable for children as it contains fragile and small parts That can be easily swallowed.

Please do not drop and or immerse in water as the unit will be damaged.

Do not expose to high temperatures or flammable gases.

Please do not remove the housing.

MAINTENANCE

-Please keep this product dry. Rain, moisture and liquids will corrode electronic Components and lines.

-Do not use this product in the high heat. High temperatures can shorten the life of

-The Product reduce battery capacity, and cause some plastic parts to melt or

Explode.

-Do not drop or knock the product. Rough handling may damage the internal

Electrical Circuit boards.

WARNINGS

-The unit may explode near or in open flames.

-The unit housing should not be opened.

-Rechargeable batteries shall not come into contact with liquids.

-The power bank should not be short-circuited or brought into contact with metal.

-Operating temperature range -20° C to 50° C.

WARRANTY AND LIABILITY

-If there is a problem with the device, please contact your dealer.

-The manufacturer is not liable for injury or damage caused by improper use.

-Modification of the product, misuse or unauthorized repair will void the warranty.

-GREEN Life Experience reserves the right to make changes to the product and

Manuals without prior notice.