

65mm\*65mm



# USER MANUAL



**AIRBEAT 320**  
Read before use.

## PACKAGE CONTENTS



1X charging case.



1 Pair Earbuds.



1X Type-C Data cable.



Extra buds.




1X User Manual.



1x cateloge/  
Warranty Card.

## PRODUCT OVERVIEW



## TOUCH CONTROL DIAGRAM

The touch area (MFB Touch Panel) is located in the upper part of earbuds handle. (MFB) Touch Panel



## WEARING EARBUDS

Note: The left earbud marked with L is worn in the left ear, and the right earbud marked with R is worn in the right ear



## POWER ON/OFF

### Power on

Auto: Open the charging case and take out the earbuds to power on  
Manually: Press and hold the MFB for 3s.



Open cover and take out the earbuds to power on

### Power off

Auto: Place both Earbud in your charging case, Close the lid.  
Manually: Press and hold the MFB for 5s.



Put earbuds in to power off


Touch to turn off

## PAIRING

Open the charging case and take out the earbuds to turn it on Automatically.



After turning on, put the left and right earphones close to each other. After the team is successful, the indicator light: the main earphone flashes white and the auxiliary earphone also flashed white light once 5 seconds




5 seconds flashing whitelight once.

white lights Alternate flashing

Open the phone's Bluetooth connection interface, search for "Airbeat-320", click pair then the connection is successful and accompanied by a tone.

## MUSIC




- ▶ Music pause/play: During playback, One click the multi-function touch button.
- ▶ Volume down: triple click the right ear multi-function touch button
- ▶ Add volume: triple click the left ear multi-function touch button
- ▶ Previous song: double the left ear multi-function touch button.
- ▶ Next song: double the right ear multi-function touch button.

## WAKE UP VOICE ASSISTANT

(requires mobile phone support)

After the connection with mobile phone is successful, except during a call, long press the multi-function touch button of the headset to activate the voice assistant function (SIRI).

## CALL



- ▶ Answer: When a call comes in, short press the multi-function touch key.
- ▶ Reject: When there is an incoming call, short press the multi-function touch key.
- ▶ Hang up: During a call, double click the multi-function touch key.

## GAMING MODE

- ▶ Quad click the right & Left ear multi-function

## CHARGING

The charging case is charged by the charging cable, when charging case is charging, the Green light flash and after the full charging, the indicator light should be on.

The earbud is placed in the charging case, automatically charged, and the earbud indicator is off after being fully charged.



Earbuds charging	White light is on
Earbuds is fully charged	light is off
Charging case is charging	Green light flash
Charging compartment is fully charged	light is on

## PRODUCT PARAMETER

- ▶ Model: Airbeat-320
- ▶ Bluetooth version: 5.4
- ▶ Single earbud weight: 4.0g
- ▶ Earbud size: 17\*15\*33mm
- ▶ Earbud battery capacity: 3.7V/2\*35mAh
- ▶ Earbud charging time: about 60 Minutes
- ▶ Play music time: about 5-6 hours(Medium volume)
- ▶ Support Agreement: A2DP,AVCTP,AVDTP,AVRCP,HFP
- ▶ Frequency: 2.4GHz~2.48GHz
- ▶ Bluetooth distance: 10M
- ▶ Charging case battery capacity: 3.7V/400mAh
- ▶ Charging case to charge the bud: 3-4 times
- ▶ Charging case size: 47\*56\*24mm
- ▶ Charging case weight: 30.3g

## EARBUDS WARNING

- ▶ Please do not place the product in an environment where the temperature is too low(above 45°C or below 0°C).
- ▶ Do not dismantle or repair the earbuds under any circumstances, if necessary, please send the product to the seller for repair.
- ▶ Do not throw and drop the earbuds to avoid damage.
- ▶ The earbuds and the BT devices will be disconnected if the distance between them is more than 10 meters.
- ▶ Keep the device and accessories away from children and pets.
- ▶ Do not put the earbuds into the washing machine.

## BATTERY WARNING

- ▶ The battery in the product may cause fire disaster or risk of chemical burning if mishandled.
- ▶ Please charge with a rated voltage charger.
- ▶ The discard of battery should obey local law, if possible please recycle it. Do not dispose it as household garbage, because it may cause a explosion.
- ▶ Users are not allowed to take out or replace battery in the product unless there is a stipulation on user manual. It is very hazardous to do this, may cause a damage to product.