


100mm

100mm

GREEN
LIFE EXPERIENCE

40 HOURS
Music Time



USER'S MANUAL


Thank you for choosing our Audio Mag Neckband. Before operating this unit, please read the USER MANUAL carefully in order to make sure that best possible performance is obtained.

1

1. Audio MAG Packaging

- 1) Audio MAG Neckband
- 2) Type-C Cable
- 3) Earbuds 2-Pairs
- 4) Warranty Card
- 5) User Manual

2. Functionality :



+ : Press once for volume up
- : Press once for volume down
○ : Long press for power ON/OFF
● : Press once for pause or play

- This neckband features smart vibration alerts for calls and notifications when connected to your phone.
- Its magnetic earbuds automatically power off when clipped together, offering convenience and power saving in one sleek design.


2

3. Specification's :

Bluetooth Version: V5.3 Charging Case Battery: 300mAh
Working Range: 10-15M Speaker: F10 horn
Working Time: ~40 hours Charging Port: Type-C

4. Features :

Applicable Equipment: Tablets, Computers, Mobile Phones



5. Charging :

Before using your Audio MAG Neckband, please make sure to charge them using the included Type-C cable. This will ensure optimal performance and battery life from the very start. Simply connect the cable to a power source and your neckband, and you'll be ready to enjoy high-quality sound in no time.

Neckband charging	Red light is on
Neckband is fully charged	Blue light is on

3


6. Neckband Warning :

Important Safety and Usage Guidelines :

- Do not expose the product to extreme temperatures (above 45°C or below 0°C).
- Do not attempt to dismantle or repair the neckband yourself. For any issues, please contact the seller for authorized repair service.
- Avoid dropping or throwing the neckband to prevent damage.
- The neckband will disconnect from Bluetooth devices if the distance exceeds 15 meters.
- Keep the device and accessories away from children and pets.
- Do not wash or submerge the neckband in water, and never put them in a washing machine.

7. Battery Warning :

- The battery in this product may cause fire or chemical burns if mishandled.
- Always use a charger with the recommended voltage.
- Dispose of the battery according to local regulations. Whenever possible, recycle. Do not throw it in household trash, as it may lead to an explosion.
- Do not attempt to remove or replace the battery unless explicitly instructed in the user manual.
- Mishandling the battery is hazardous and may damage the product.



4