

75mm\*75mm  
128g

## Mag Booster



POWER BANK

## USER MANUAL

Please refer to this manual before using the product

### INTRODUCTION

Thank you for choosing "The Mag Booster" portable wireless power bank. This product is a rechargeable battery (power bank) that can be used to power Mobile devices.

The stored energy after a full charge is about 10000mAh which will provide an Output of 22.5W from the USB & Type-c Attach wire, 20W from USB-Type-C, 15W From the wireless output and 10W from Lighting Attach wire. For the best use of The power bank and for your safety, please read these instructions carefully.




Magnet.  
15W wireless charger.

### INTRODUCTION

Thank you for choosing "The Mag Booster" portable wireless power bank. This product is a rechargeable battery (power bank) that can be used to power Mobile devices.

The stored energy after a full charge is about 10000mAh which will provide an Output of 22.5W from the USB & Type-c Attach wire, 20W from USB-Type-C, 15W From the wireless output and 10W from Lighting Attach wire. For the best use of The power bank and for your safety, please read these instructions carefully.



PACKAGE CONTAINS  
1X POWERBANK.  
1X TYPE-C DATA CABLE.

### TO CHARGE POWER BANK

To charge the power bank, use the included USB-A to USB-C cable and connect it to The input port on the power bank alternatively you can also use PD input cable as Well.

**\*MAKE SURE TO USE THE ORIGINAL MINIMUM 18W SUPER FAST CHARGING ADAPTER**

While charging the power bank, digital display which shows the battery percentage Of power bank will flash to indicate charging status. If you are using a fast-charging Adapter it will show the fast-charging icon on the display.



Fast charging icon

When charging is completed the percentage shows 100% on the display.

### TO CHARGE PHONE OR DEVICE

To charge your device, connect a USB-A cable to the output port on the power bank And plug the other end into your device, or use a USB-C cable by connecting it to the USB-C port on the power bank and then to your device; Alternatively, you can use a USB-C or Lightning attach cable directly to your device. if your device supports Wireless charging, simply place the back of your device against the power bank and It should start charging automatically; if it doesn't, press the On/Off button on the Power bank to begin charging.

### TO CHECK REMAINING CAPACITY

Press the On/Off button and the digital display will show the percentage of Remaining capacity. The digital display will turn off automatically after about 30 seconds.

### SPECIFICATIONS

Model Name: Mag Booster  
Battery type: Lithium-Polymer  
Battery capacity: 10000mAh.  
Input Power: 5V/3A, 9V/2A,  
Output Power:  
Attach Type-c: 5V/3A, 9V/2.22A, 12V/1.67A, 10V/2.25A  
Attach Lighting: 5V/2A  
USB-C: 5V/3A, 9V/2.22A, 12V/1.67A  
USB-A: 5V/3A, 9V/2A, 10V/2.25A, 12V/1.5A  
Wireless: 15W

### SAFETY

Use only original adapter for charging, otherwise you may cause damage to the Device. The product is not suitable for children as it contains fragile and small parts That can be easily swallowed.  
Please do not drop and or immerse in water as the unit will be damaged.  
Do not expose to high temperatures or flammable gases.  
Please do not remove the housing.

### MAINTENANCE

-Please keep this product dry. Rain, moisture and liquids will corrode electronic Components and lines.  
-Do not use this product in the high heat. High temperatures can shorten the life of  
-The Product reduce battery capacity, and cause some plastic parts to melt or Explode.  
-Do not drop or knock the product. Rough handling may damage the internal Electrical Circuit boards.

### WARNINGS

-The unit may explode near or in open flames.  
-The unit housing should not be opened.  
-Rechargeable batteries shall not come into contact with liquids.  
-The power bank should not be short-circuited or brought into contact with metal.  
-Operating temperature range -20° C to 50° C.

### WARRANTY AND LIABILITY

-If there is a problem with the device, please contact your dealer.  
-The manufacturer is not liable for injury or damage caused by improper use.  
-Modification of the product, misuse or unauthorized repair will void the warranty.  
-GREEN Life Experience reserves the right to make changes to the product and Manuals without prior notice.