

75mm*75mm
128g



Power Boost POWER BANK USER MANUAL

we prefer to read this user manual, before using the product.

INTRODUCTION

Thank you for choosing the "Power Boost" Portable Power Bank a rechargeable battery designed to power mobile devices, with a storage capacity of approximately 20,000mAh, offering 22.5W output from the USB port, 22.5W output from the USB Type-C port, and supporting up to 18W input for fast charging; for optimal performance and your safety, please read these instructions carefully before use.



PACKAGE CONTAINS
1X POWERBANK.
1X TYPE-C DATA CABLE.

TO CHARGE POWER BANK

To charge the power bank, use the included USB-A to USB-C or Micro USB cable and connect it to the input port on the power bank; alternatively, you can use the PD input cable.

Make sure to use the original Super Fast Charging adapter with a minimum output of 18W.

While the power bank is charging, the LED indicators will flash to show the charging status. When charging is complete, all four LED lights will stop flashing and remain solid.

TO CHARGE PHONE OR DEVICE

Use your phone's or other device's charging cable to connect the USB-A connector to the output port on the power bank, and plug the other end into your device; charging should begin automatically. If your device uses a USB-C (PD) cable, you can also connect it directly to the USB-C port on the power bank.

If charging does not start automatically, press the power bank's On/Off button to begin charging.

TO CHECK REMAINING CAPACITY

Press the On/Off button to check the remaining battery capacity; the LED indicators will light up, where 1 light indicates 25%, 2 lights indicate 50%, 3 lights indicate 75%, and 4 lights indicate 100% charge remaining. The LED lights will turn off automatically after approximately 30 seconds.

SPECIFICATIONS

Model Name: Power Boost
Battery type: Lithium-Polymer
Battery capacity: 20000mAh.
Input Power:
Type-c: 5V/3A, 9V/2A, 12V/1.5A
Micro:5V/2A, 9V/2A, 12V/1.5A
Output Power:
USB-A: 5V/3A, 9V/2A, 10V/2.25A, 12V/1.5A
USB-C: 5V/3A, 9V/2.22A, 10V/2.25A, 12V/1.67A

SAFETY

Use only original adapter for charging, otherwise you may cause damage to the Device. The product is not suitable for children as it contains fragile and small parts that can be easily swallowed.
Please do not drop and or immerse in water as the unit will be damaged.
Do not expose to high temperatures or flammable gases.
Please do not remove the housing.

MAINTENANCE

Please keep this product dry. Rain, moisture and liquids will corrode electronic Components and lines.
Do not use this product in the high heat. High temperatures can shorten the life of the Product reduce battery capacity, and cause some plastic parts to melt or Explode.
Do not drop or knock the product. Rough handling may damage the internal Electrical Circuit boards.

WARNINGS

The unit may explode near or in open flames.
The unit housing should not be opened.
Rechargeable batteries shall not come into contact with liquids.
The power bank should not be short-circuited or brought into contact with metal.
Operating temperature range -20° C to 50° C.

WARRANTY AND LIABILITY

If there is a problem with the device, please contact your dealer.
The manufacturer is not liable for injury or damage caused by improper use.
Modification of the product, misuse or unauthorized repair will void the warranty.
GREEN Life Experience reserves the right to make changes to the product and Manuals without prior notice.