



Introduction


Thank you for choosing the Symphony Wireless Noise-Canceling Headphones. This manual will guide you through operating the Symphony headphones, but first, it is essential to familiarize yourself with the Bluetooth function of your phone or other devices before using the Symphony headphones.

Package Contents

- 1 x Symphony Headphone
- 1 x Charging cable
- 1 x Shining outer caps
- 1 x User manual
- 1 x catalogue/Warranty card



Button Functions



How to Use

- Turn On and:** Press and hold the power button for 3 seconds.
- Enter Pairing Mode:** After powering on, the LED indicator will alternate between flashing orange and white
- Pairing:** Pair with a Bluetooth-enabled phone or other Bluetooth devices. Once pairing is completed, the LED indicator will turn off.
- Turn Off:** Press and hold the power button for 5 seconds.
- Charging:** Insert the Type-C plug into the Type-C port. While charging, the indicator will turn orange. When charging is complete, the LED indicator will turn off.
- Answer Calls:**
 - Press the power button to answer a call.
 - Press the power button again to end the call.
 - Press and hold the power button for 2 seconds to reject a call
 - Double press the power button to redial the last dialed number.
- Play/Pause, Music:** Short press the power button to play or pause music.
- ANC Mode:** Short press the ANC button to activate ANC mode. The ANC indicator will stay white.

Pairing with Devices

To use the Bluetooth headphones, you must first pair them with your mobile phone or other Bluetooth devices. Once your Bluetooth headphones are successfully paired with a specific mobile phone, they will remain paired and automatically recognize each other within range.

The process for pairing device is as follows:

- 1) Turn on your phone and ensure that the Bluetooth function is activated.
- 2) Turn on the headphones and enter pairing mode.
- 3) Follow the instructions on your phone to search for Bluetooth devices. Refer to your phone's user manual for more information.
- 4) After a few seconds, your phone will list symphony as a discoverable device. Select it and follow the instructions on your phone to complete the pairing process.
- 5) Your phone will confirm the pairing request, please press "Yes"/"OK".

Charging Instructions

For your safety, please always use an appropriate 5V input charger/adaptor to charge the product. Do not use Type-C fast chargers, as this may damage the product.

Connect the Type-C plug to the Type-C charging port on the headphones. Then, connect the other end of the Type-C plug to a USB port on your computer or adapter to activate charging.

Before initial use, ensure the headphones are charged for at least 2 hours to ensure a full charge.



The Type-C charging cable provided with this product is intended for use with this product only. Please only use the provided Type-C charging cable for charging.

Warning

You must select a qualified charger manufacturer. If the Bluetooth headphones have not been used for more than 6 months, they must be charged.

Product Specifications

Speaker Diameter:	40 mm
Impedance:	32 ohms
Frequency Response:	20 Hz - 20kHz
Sensitivity:	110dB ± 3dB
Battery Specifications:	Lithium battery, 3.7V/1000mAh
Noise Reduction Depth:	40±2dB
Charging Time:	Approx. 2.5 hours
Bluetooth Range:	10m
Bluetooth Version:	5.4
Playtime:	100 hours (BT), 80 hours (ANC)

Hybrid Active Noise Cancellation (ANC) |
 Spatial Audio technology |
 100H Playtimes (Bluetooth), 80H Playtimes (with ANC)

CHANGEABLE CAP |
 45 ms LOW LATENCY GAMING |
 5 CAR AND PERSONALIZED NOISE-CANCELING MIC

Safety Instructions

The input voltage for the product is 5V 1A. To ensure safe and reliable charging of the product, please only use certified and appropriate chargers/adapters. Only charge in environments with temperatures ranging from 10°C (50°F) to 40°C (104°F). Do not expose to heat exceeding 70°C (158°F), such as direct sunlight or fire. Turn off the product after use. Please note that we will not be liable for any misuse (e.g., voltage exceeding 5V), as this may result in serious injury or property damage, and we cannot control user actions during product use. In extreme cases, misuse or abuse of the lithium battery pack may result in explosion, heating, fire, or smoke.

